

Pneumocystis sp., Animal Control Slides – Technical Memo

CONTROL SLIDES: Part 4556A Part 4556B 10 Slide/Set 98 Slide/Set

PRODUCT SPECIFICATIONS:

Tissue: Positive staining primate lung and negative staining human lung.

Fixation: Formalin 10%, Phosphate Buffered (Part 1090).

Section/Glass: Paraffin sections cut at 4 microns on Superfrost™ Plus slides.

Quality Control Stain: Grocott Methenamine Silver quality control stained slide(s) included.

Reactivity: Guaranteed product specific reactivity for one year from date of receipt. Revalidate after one year to verify continued reactivity.

Storage: 15-30°C in a light deprived and humidity controlled environment.

Intended Use: To verify histological techniques and reagent reactivity.

Before using unstained control slides, review the enclosed stained slide(s) to ensure that this tissue source is acceptable for testing needs.

CONTROL SLIDE VALIDATION:

Part 9121A/B	Individual Stain Solution
250/500 ml	Part 10341
250/500 ml	Part 13821
125/250 ml	Part 1142
125/250 ml	Part 1142
250/500 ml	Part 11285
250/500 ml	Part 13888
250/500 ml	Part 12202
	250/500 ml 250/500 ml 125/250 ml 125/250 ml 250/500 ml 250/500 ml

APPLICATION:

Newcomer Supply *Pneumocystis sp.*, Animal Control Slides are for the positive histochemical staining of fungal organisms. The morphology of the organisms is consistent with *Pneumocystis sp.*

PRESTAINING PREPARATION:

- 1. Heat dry sections in oven according to your laboratory protocol.
- 2. All glassware/plasticware must be acid cleaned prior to use.
 - a. See Procedure Notes #1 and #2 (page 2).
- 3. Prepare Silver-Methenamine Working Solution and mix well:
 - a. Solution C: Silver Nitrate 20 ml
 - b. Solution D: Methenamine Borate 20 ml
- Preheat Silver-Methenamine Working Solution to 45°C-60°C in a water bath approximately 20 to 30 minutes before use.
 - a. See Procedure Note #3 (page 2).
 - b. Do not preheat if using Microwave Modification; Step 11.

NEWCOMER SUPPLY VALIDATION PROCEDURE:

- Deparaffinize sections thoroughly in three changes of xylene, 3 minutes each. Hydrate through two changes each of 100% and 95% ethyl alcohols, 10 dips each. Wash well with distilled water.
 - a. See Procedure Notes #4 and #5 (page 2).
- 6. Oxidize in Solution A: Chromic Acid 5%, Aqueous for 1 hour.

Microwave Modification: See Procedure Note #6 (page 2).

- a. Oxidize slides in a <u>plastic</u> Coplin jar containing Solution A: Chromic Acid 5%, Aqueous and microwave for 1 minute and 20 seconds at 60°C.
- 7. Wash well in running tap water; rinse in distilled water.
- 8. Place in Solution B: Sodium Bisulfite 1%, Aqueous for 1 minute.
- 9. Wash for 5 minutes in running tap water; rinse well in distilled water.
- Incubate slides in preheated Silver-Methenamine Working Solution (Step #4) at 45°C-60°C or at room temperature, for 12-18 minutes until sections appear paper-bag brown.
 - Periodically remove control, rinse in <u>warm</u> distilled water, check microscopically for adequate silver impregnation. Fungi should be dark brown.
 - b. If organisms are not sufficiently dark, return slides to warm silver solution. Recheck at 2-3 minute intervals until desired intensity is achieved.
 - c. Pneumocystis may take longer to stain than other fungus.
 - d. Staining at room temperature will require longer incubation.

11. Microwave Modification:

 Incubate slides in a <u>plastic</u> Coplin jar containing Silver-Methenamine Working Solution and microwave for 1 minute at 70°C.

Part 4556 Revised May 2020


- b. Check microscopically for adequate development.
- c. If additional incubation is required, return slides to warm silver solution. Recheck at 2-3 minute intervals.
- 12. Rinse in three to four changes of distilled water.
 - a. Never use tap water at this step.
- 13. Tone in Solution E: Gold Chloride 0.1%, Aqueous until sections turn gray; 20 seconds to 1 minute.
- 14. Rinse well in distilled water.
- Remove unreduced silver in Solution F: Sodium Thiosulfate 2%, Aqueous for 2 minutes.
- 16. Wash in running tap water for 5 minutes; rinse in distilled water.
- Counterstain in Solution G: Light Green SF Yellowish Stain 0.2%, Aqueous for 2 minutes.
- Dehydrate quickly in two changes each of 95% and 100% ethyl alcohol. Clear in three changes of xylene, 10 dips each; coverslip with compatible mounting medium.

RESULTS:

Pneumocystis sp. Sharply outlined in black

Background Pale green

Negative lung Negative for fungal organisms



SUPPORT/WARRANTY: For assistance regarding this product contact Newcomer Supply at 800-383-7799 or info@newcomersupply.com. The information presented in this technical memo is to the best of our knowledge accurate. No warranty is expressed or implied. The user is responsible for determining the suitability of this product for their use and upon receipt assumes all liability for its use and responsibility for compliance with any laws or regulations. Please refer to www.newcomersupply.com for complete warranty information. © Newcomer Supply, Inc., 2020

2505 Parview Road • Middleton, WI 53562-2579 • 800-383-7799 • www.newcomersupply.com • info@newcomersupply.com

PROCEDURE NOTES:

- Acid clean all glassware/plasticware (12086) and rinse thoroughly in several changes of distilled water.
- Plastic (5500), plastic-tipped or paraffin coated metal forceps must be used with any silver solution to prevent precipitation of silver salts. No metals of any kind should be in contact with any silver solution. Only glass thermometers should be used.
- Staining at higher temperatures means faster development but may cause precipitate to form in the working silver solution and deposit on slides. Maintaining silver solution between 45°C-60°C will minimize precipitate.
- 4. Drain slides after each step to prevent solution carry over.
- 5. Do not allow sections to dry out at any point during procedure.
- The suggested microwave procedure has been tested at Newcomer Supply. This procedure is a guideline and techniques should be developed for use in your laboratory.
- If using a xylene substitute, closely follow the manufacturer's recommendations for deparaffinization and clearing steps.

REFERENCES:

- Carson, Freida L., and Christa Hladik. Histotechnology: A Self-Instructional Text. 3rd ed. Chicago, Ill.: American Society of Clinical Pathologists, 2009. 239-243.
- 2. Grocott, R G, "A Stain for Fungi in Tissue Sections and Smears using Gomori Methenamine Silver Nitrate Technic". *American Journal of Clinical Pathology* 25 (1955): 975-979.
- Koski, John. "Silver Methenamine Borate (SMB): Cost Reduction with Technical Improvement in Silver Nitrate-Gold Chloride Impregnations." The Journal of Histotechnology 4.3 (1981): 115-119
- Sheehan, Dezna C., and Barbara B. Hrapchak. Theory and Practice of Histotechnology. 2nd ed. St. Louis: Mosby, 1980. 245-246
- 5. Modifications developed by Newcomer Supply Laboratory.