

Jones Basement Membrane Silver Set - Technical Memo

SET INCLUDES:

Solution A: Methenamine 3%, Aqueous
Solution B: Silver Nitrate 5%, Aqueous
Solution C: Sodium Borate 5%, Aqueous

Part 1131A

250 ml
50 ml
50 ml

Individual stain solutions may be available for purchase under separate part numbers at www.newcomersupply.com.

Additionally Needed For Jones Basement Membrane Stain:

Basement Membrane Control Slides	Part 4055
Hydrochloric Acid 5%, Aqueous	Part 12086 (for acid cleaning glassware)
Periodic Acid 1%, Aqueous	Part 13304
Gold Chloride 0.25%, Aqueous	Part 11287
Sodium Thiosulfate 2.5%, Aqueous	Part 13889
Light Green SF Yellowish Stain 0.1%, Aqueous	Part 12203
Xylene, ACS	Part 1445
Alcohol, Ethyl Denatured, 100%	Part 10841
Alcohol, Ethyl Denatured, 95%	Part 10842
Coplin Jar, Plastic	Part 5184 (for microwave modification)

For storage requirements and expiration date refer to individual product labels.

APPLICATION:

The Newcomer Supply Jones Basement Membrane Silver Set provides the silver staining solutions for the Jones Basement Membrane Stain for identification of glomerular and tubular basement membranes in renal tissue. This procedure is also referred to as the Periodic Acid-Methenamine Method (PAMM).

METHOD:

Fixation: Formalin 10%, Phosphate Buffered (Part 1090)
Technique: Paraffin sections cut at 4 microns
Solutions: All solutions are manufactured by Newcomer Supply, Inc.

All Newcomer Supply Stain Sets are designed to be used with Coplin jars filled to 40 ml following the provided staining procedure. Some solutions in the set may contain extra volumes.

PRESTAINING PREPARATION:

1. If necessary, heat dry tissue sections/slides in oven.
2. All glassware/plasticware must be acid cleaned prior to use.
 - a. See Procedure Notes #1 and #2 (page 2).
3. Prepare Silver-Methenamine Working Solution and mix well:
 - a. Solution A: Methenamine 3%, Aqueous 40 ml
 - b. Solution B: Silver Nitrate 5%, Aqueous 2 ml
 - c. Solution C: Sodium Borate 5%, Aqueous 4 ml
4. Preheat Silver-Methenamine Working Solution to 45°-60°C in a water bath 20-30 minutes before use.
 - a. Maintain solution between 45°-60°C to minimize precipitate.
 - b. **Do not preheat solution if using Microwave Modification.**

STAINING PROCEDURE:

5. Deparaffinize sections thoroughly in three changes of xylene, 3 minutes each. Hydrate through two changes each of 100% and 95% ethyl alcohols, 10 dips each. Wash well with distilled water.
 - a. See Procedure Notes #3 and #4 (page 2).
6. Place in Periodic Acid 1%, Aqueous (13304) for 15 minutes.
7. Wash in tap water for 5 minutes; rinse in distilled water.
8. Incubate slides in preheated Silver-Methenamine Working Solution (Step #4) at 45°-60°C or at room temperature for 12-18 minutes until sections appear paper-bag brown.

9. Periodically remove control, rinse in warm distilled water, check microscopically for adequate silver impregnation. Basement membranes should be dark brown. If tissue structures are not sufficiently dark, return slides to warm silver solution. Recheck at 2-3 minute intervals until desired intensity is achieved.
 - a. Staining at room temperature will require longer incubation.
10. **Microwave Modification:** See Procedure Note #5 (page 2).
 - a. Place slides in a plastic Coplin jar with prepared Silver-Methenamine Working Solution (Step #3). Microwave at 70°C for 3 minutes.
 - b. Check microscopically for adequate development.
 - c. If additional incubation is required, return slides to heated silver solution and recheck at regular intervals.
11. Rinse in three changes of distilled water.
12. Tone in Gold Chloride 0.25%, Aqueous (11287) for 1 minute.
13. Rinse well in three changes of distilled water.
14. Place in Sodium Thiosulfate 2.5%, Aqueous (13889) for 2 minutes.
15. Wash in tap water for 5 minutes; rinse in distilled water.
16. Counterstain in Light Green SF Yellowish Stain 0.1%, Aqueous (12203) for 1 minute.
17. Quickly rinse slides in two changes of distilled water.
18. Dehydrate in two changes each of 95% and 100% ethyl alcohol. Clear in three changes of xylene, 10 dips each; coverslip with compatible mounting medium.

RESULTS:

Kidney glomerular basement membranes	Black
Intra-glomerular deposits	Black
Reticular fibers	Black
Nuclei	Outlined in black
Cytoplasm	Light green

PROCEDURE NOTES:

1. Acid clean all glassware/plasticware (12086) and rinse thoroughly in several changes of distilled water.
2. Plastic (5500), plastic-tipped or paraffin coated metal forceps must be used with silver solutions to prevent precipitation of silver salts. No metals of any kind should come in contact with silver solutions. Only glass thermometers should be used.
3. Drain slides after each step to prevent solution carry over.
4. Do not allow sections to dry out at any point during procedure.
5. The suggested microwave procedure has been tested at Newcomer Supply. This procedure is a guideline and techniques should be developed for use in your laboratory.
6. If using a xylene substitute, follow the manufacturer's recommendations for deparaffinization and clearing steps.

REFERENCES:

1. Jones, David B. "Nephrotic Glomerulonephritis," *American Journal of Pathology* 33.2 (1957): 313–329.
2. Luna, Lee G. *Manual of Histologic Staining Methods of the Armed Forces Institute of Pathology*. 3rd ed. New York: Blakiston Division, McGraw-Hill, 1968. 97-99.
3. Sheehan, Dezna C., and Barbara B. Hrapchak. *Theory and Practice of Histotechnology*. 2nd ed. St. Louis: Mosby, 1980. 187-188.
4. Modifications developed by Newcomer Supply Laboratory.